



GETTING STARTED GUIDE

YOUR DZBOTICS DESK ROBOT

Digi-pet reimagined

A palm-sized companion that plays, reminds, breathes with you, and keeps you company — right from your desk.



www.dzbotics.com

Welcome

Thanks for bringing home your new DZbotics robot. It is a tiny desk companion with a big personality — it has moods, plays games, runs focus timers, guides your breathing, tells jokes, and throws a party on demand. Everything happens on its little screen, controlled with three touch spots and a glowing light.

This guide walks you through setup and everyday use. No technical knowledge needed — if you can tap and hold, you can use your robot.

Meet your robot

Take a moment to get familiar with the four things you will use most:

- **OLED face screen** — the small display where your robot shows its eyes, menus, games, and messages.
- **Touch spots (3)** — capacitive pads you tap or hold: one in the centre (the belly) and one on each side of the head (left and right).
- **LED glow** — a colour light underneath that reacts to what the robot is doing.
- **USB power** — plug it in with a standard USB cable to switch it on. There is no power button.



Touch Controls

Your robot has three touch spots. Everything is done by tapping or holding them.

The three touch spots

TOUCH SPOT	WHAT IT IS FOR
Centre (belly)	Open the menu, confirm, or do the main action. Hold it to exit.
Left (head)	Move back through a menu or list. Also feeds your pet.
Right (head)	Move forward through a menu or list. Also plays with your pet.

Gestures

DO THIS	AND IT WILL
Tap the centre (from the home face)	Open the menu.
Tap the centre (anywhere else)	Confirm, select, or do the main action.
Tap left or right	Move through the menu or a list, one item at a time.
Hold the centre (about 1 sec)	Exit whatever you are in and return home.
Touch either side of the head	Your robot reacts to being petted on the head.
Hold left + right together	A tummy tickle — your robot giggles.

TIP

When in doubt, hold the centre spot for a moment — that always takes you back home.

First-Time Setup

Power on

Connect your robot to power using a USB cable and any standard phone charger or laptop port. It starts up on its own and shows a friendly boot screen, then its face — no accounts, no apps, and no network setup required. Everything works right out of the box.

The Menu

To open the menu: from the home face, tap the centre touch spot. Tap left or right to scroll through the items, and tap the centre again to open the one you want. The menu closes on its own if you leave it alone for 10 seconds.

MENU ITEM	WHAT IT DOES
Timer	A focus / Pomodoro countdown timer.
Games	Six mini-games to play.
Quotes	Browse a library of motivational quotes.
Jokes	Programming and pun jokes, with a delayed punchline.
Calm	A guided calm-down breathing exercise.
LED	Turn the glow light on or off.
Pet	Care for your robot as a virtual pet.
Party	Party mode — a dance animation with disco lights.
Info	Your robot's serial number and firmware version.

TO LEAVE ANY ITEM

Hold the centre spot for a moment to return home. Party mode and the Info screen close on a single tap of the centre instead.

Your Virtual Pet


At its heart, your robot is a digital pet. It has three needs that slowly drop over time, just like a real companion:

- **Hunger** — feed it to keep it full.
- **Happiness** — play with it to keep its spirits up.
- **Energy** — let it sleep to recharge.

When a need gets low, your robot shows it on its face — a hungry, sad, or sleepy look. Open the **Pet** menu to take care of it.

Caring for your pet

- **Feed** — tap left to drop a fish treat and fill hunger.
- **Play** — tap right for a quick play animation that lifts happiness.
- **Sleep** — tap the centre for a short nap that restores energy.
- **Pet it** — touch either side of its head for a petting reaction, or hold both together for a tummy tickle. This works from the home face too.



DON'T NEGLECT IT

If all the needs stay very low for a long stretch, your robot can get "sick" and will need some extra attention and care to bounce back. Your robot remembers its health, age, and how often you have interacted, even after you unplug it.

Things To Do

Focus Timer

A Pomodoro-style countdown, set to 20 minutes by default. Tap left or right to adjust the time in 5-minute steps; tap the centre to start, pause, or resume. Your robot throws up two thumbs and the light celebrates when your session is done. Hold the centre to leave.

Games

Six quick, penguin-themed mini-games. Your best score or win count is saved for each one. The first four open with a short screen explaining the controls — tap the centre to skip it. To leave a game, hold the centre spot for a moment.

- **Catch Fish** — a reflex catching game.
- **Iceberg Hopping** — jump from platform to platform.
- **Snowball Dodge** — dodge the obstacles.
- **Ice Sliding** — slide and steer with momentum.
- **Tic Tac Toe** — pick X or O and play against your robot. Fair warning: it does not lose.
- **Rock Paper Scissors** — best of three. Hold a touch spot as the countdown hits zero.

Quotes & Jokes

Tap left or right to browse 50+ motivational quotes or 50+ jokes any time. Jokes show the setup first, then reveal the punchline after a short pause. A random quote or joke also pops up about once an hour.

Calm (Breathing Coach)

A guided exercise to help you relax: breathe in for 4 seconds, hold for 4, and breathe out for 6, repeated twice — about 30 seconds in all. Animated water rises and falls with your breath while the light pulses a soft blue. Afterwards your robot asks whether you feel better, and may offer you a game.

Party Mode

Your robot breaks into a dance animation while the glow light runs a disco routine. It keeps going until you tap the centre spot once to stop it. Best deployed when someone walks past your desk.

LED & Info

The LED item turns the glow light on or off — your choice is remembered, even after unplugging. Info shows your robot's serial number and firmware version; tap the centre to close it.

Reminders & Care

Gentle reminders

While it is running, your robot looks out for you:

- **Water reminder** — a nudge to drink water roughly every 30 minutes.
- **Break prompt** — every few hours it suggests a short break. Say yes and it opens the games menu for you.
- **Posture check** — an hourly nudge to sit up straight.
- **Check-in** — about once an hour it asks how your day is going. Answer with left (good), right (great), or the centre (horrible) — and it will try to cheer you up.
- **Hourly pick-me-up** — a surprise quote or joke about once an hour.

Works entirely offline

Your robot works entirely offline — no accounts, no cloud, and no network needed. Everything it does runs right on the device, so it is ready the moment you plug it in and your data never leaves your desk.

Troubleshooting

IF...	TRY THIS
The screen is blank	Check the USB cable and power source; reconnect to restart.
You're stuck in a feature	Hold the centre touch spot for a moment to return home.

NEED A HAND?

Visit www.dzbotics.com for support, guides, and updates. Made with care in India.